




TOP AND CABINET PARTS

For Models: LSR8010PQ0, LSR8010PT0
(Designer White) (Biscuit)

AUTOMATIC
WASHER



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP AND CABINET PARTS

For Models: LSR8010PQ0, LSR8010PT0
(Designer White) (Biscuit)

Illus. No.	Part No.	DESCRIPTION
1		Literature Parts
	LIT3956025	Installation Instructions
	LIT3955869	Use & Care Guide
	LIT3955907	Feature Sheet
	LIT3956910	Energy Guide
	LIT8541944	Wiring Diagram


Following May Be Purchased

DO-IT-YOURSELF REPAIR MANUALS

	LIT4313896	Manual, Washer
2		Top
	8318064	White
	8318066	Biscuit
3	62750	Spacer, Cabinet To Top (4)
4	357213	Nut, Push-In (2)
5		Cabinet
	63424	White
	3954357	Biscuit
6	62780	Clip, Top & Cabinet & Rear Panel (2)
7	3362952	Dispenser, Bleach
8	3351614	Screw, Ground
9	3357011	Screw, 10-16 x 1/2
11	8318084	Switch, Lid
13	3351355	Screw, Lid Hinge Mounting (4)
15	8318088	Hinge, Lid (L.H.)
16	54583	Hinge, Lid (R.H.)
17	19119	Bumper, Lid Hinge
18	21258	Bearing, Lid Hinge (2)
19		Lid
	8542387	White
	8542384	Biscuit
22	9724509	Bumper, Lid (2)
28	3390631	Screw, 10-16 x 3/8

CONTROLS AND REAR PANEL PARTS

For Models: LSR8010PQ0, LSR8010PT0
(Designer White) (Biscuit)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROLS AND REAR PANEL PARTS


For Models: LSR8010PQ0, LSR8010PT0
(Designer White) (Biscuit)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	3976300	Washer, Water Inlet Hose (4) (1-1/16 x 5/8)	15	3952821	Strain Relief, Power Cord	36	3400818	Screw, Timer
2	3400073	Screw, Ground	16	8271365	Cap, End (L.H.)	37	3949180	Switch, Rotary Mounting
3		Hose, Water Inlet (2)		8271368	White Biscuit	39		Panel, Console
	3949374	Blue Coupler	17	661606	Capacitor, Motor Start		3956561	White Biscuit
	3949375	Red Coupler	18	3952164	Valve, Water Mixing	44	3956562	Knob, Timer
4	9740848	Screw					8544943	White Biscuit
5	8318255	Strap, Console (2)	19	694419	Mini-Buzzer	45	8544944	Dial, Timer
6	3357978	Panel, Rear	20	8318046	Clip, Capacitor		8544947	White Biscuit
7	62747	Pad, Rear Panel	21	301958	Clamp, Hose		8544948	Biscuit
8	3951609	Hose, Drain (4 ft.)	22	8541607	Hose, Vacuum Break	46	8536939	Clip, Knob
	661577	Hose, Drain (9 ft.) (Not Included)	23	370450	Clamp, Hose	47		Knob, Control
	3357090	Extension Drain-Hose (21 Inches) (Not Included)	24	387606	Break, Vacuum		8544935	White Biscuit
			25	303294	Edge Protector	49	388326	Screw, 8-18 x 1.25 (Panel to Top)
9	8541942	Timer, Control (60 Hz.) (Motor Not A Service Part)	26	8317940	Hose-Corrugated Assembly	50	62863	Screw, 10-16 x 3/8
10	3351614	Screw, Ground	27	3366912	Clamp, Hose	51		Cap, End (R.H.)
11	90767	Screw, 8-18 x 3/8	28	3976395	Clamp, Hose		8271359	White Biscuit
12	3366845	Switch, Water Level	29	3347812	Clip, Harness		8271362	Biscuit
13	3948608	Bracket, Control	30	3363366	Clamp, Hose	58	3366913	Clamp, Drain Hose
14	661661	Cord, Power (Includes Item 15)	31	8317496	Clamp, Hose	59	8539874	Shield, Suds
			32	3951449	Hose, Pump To Tub	60	3357027	Nozzle-Drain Hose
			33	8055003	Clip, Harness & Pressure Hose	61	3957015	Wiring Harness (For Detail See Pages 9 & 10)
			34	8317975	Retainer, Harness			
			35	661612	Switch, Water Temperature			

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

AGITATOR, BASKET AND TUB PARTS

For Models: LSR8010PQ0, LSR8010PT0
(Designer White) (Biscuit)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

AGITATOR, BASKET AND TUB PARTS


For Models: LSR8010PQ0, LSR8010PT0
(Designer White) (Biscuit)

Illus. No.	Part No.	DESCRIPTION
1	63580	Dispenser, Fabric Softener
2	358237	Screw & Washer (5/16-24 x 1)
3	3348752	Clothes Mover
4	3347288	Agitator
5	8528150	Tub Ring & Gasket
6	3976308	Gasket, Tub Ring
7	3354845	Clip, Agitator
8	3355921	Washer, Agitator
9	3363663	Cam, Driven
10	3366877	Dog, Agitator Clutch
11	3363661	Bearing, Cam Driven
12	21366	Nut, Spanner
13	8526016	Basket & Balance Ring
15	8519788	Balance Ring
16	63849	Tub
17	389140	Block, Basket Drive
18	383727	Gasket, Centerpost
19	3347780	Hose, Pressure Switch
20	3348117	Agitator (Complete)
22	3350389	Spacer, Thrust
23	3354733	Cap, Barrier
24	3348855	Seal, Inner Cap
26	3949550	Washer

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST


BRAKE, CLUTCH, GEARCASE, MOTOR AND PUMP PARTS

For Models: LSR8010PQ0, LSR8010PT0
(Designer White) (Biscuit)



Illus. No.	Part No.	DESCRIPTION
1	388952	Brake & Drive Tube (Complete) (Refer to Page 11 For Further Breakdown)
2	63292	Washer, Spin Tube Thrust
3	62697	Ring, Spin Tube Support
4	63283	Ring, Retainer
5	3951311	Clutch (Complete)
6	3951308	Band & Lining, Clutch (Includes Illus. 7 & 8)
7	62646	Cap, Clutch Spring (2)
8	3946792	Spring, Clutch
9	3360630	Gearcase (Complete) (Refer To Page 12 For Further Breakdown)

Illus. No.	Part No.	DESCRIPTION
10	3357334	Screw, Gearcase To Base (3)
11	62611	Plate, Motor Mount To Gearcase
12	62691	Grommet, Motor (4)
13	285753	Coupling, Motor & Isolation
15	3355454	Clip, Anti-Rattle
16	3400516	Screw
17	3349637	Retainer, Motor (2)
18	3362089	Shield, Tub To Motor
19	8528157	Motor, Main Drive
20	3952056	Switch, Main Drive Motor
21	8546127	Retainer, Pump (2)
22	3363394	Pump (Complete)
23	3387485	Screw, 10-16 x 5/8
24	3946532	Shield, Motor




FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

MACHINE BASE PARTS

For Models: LSR8010PQ0, LSR8010PT0

(Designer White) (Biscuit)




Illus. No.	Part No.	DESCRIPTION
1	3400076	Screw, Bracket Mounting (10-32 x 5/8)
2	64067	Bracket, Spring Outer (2)
3	63907	Spring Suspension,(3)
4	3362087	Support & Brake, Tub
5	64065	Bracket, Spring Outer (L.F.)
6	63466	Link, Leveling Mechanism (2)
7	62597	Spring, Leveling Mechanism
8	62837	Pin, Knurled
9	62596	Foot, Rear (2)
13	3347047	Bearing, Centerpost (2)
14	357409	Seal, Centerpost (3)
15	388492	Spring, Counterweight
16	62568	Pad, Plate
17	3946509	Plate, Suspension (Includes Illus. 16)
18	3363660	Pad, Base
19	3946512	Base Assembly (Includes Illus. 6, 7, 8, 9, 16, 17 18 & 26)
21	3359452	Nut, Lock (2) (3/8-16)
22	389102	Foot, Front (2)
23	356934	Seal, Centerpost (2)
24	285203	Centerpost Bearing Kit (Includes Illus. 13, 14 & 23)
25	63134	Ring, Sound Deadening
26	63806	Retainer, Suspension Spring

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

WIRING HARNESS PARTS

For Models: LSR8010PQ0, LSR8010PT0
(Designer White) (Biscuit)



WH2H

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

WIRING HARNESS PARTS

For Models: LSR8010PQ0, LSR8010PT0
(Designer White) (Biscuit)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	3349557	Clip, Harness	10	62889	Receptacle, Terminal (3-Way) (Lid Switch) (Use Term.94613) Or 94614.)	17	3390423	Block, Disconnect (12-Way) (Timer) (Use Term. 94613)
2	388498	Clip, Harness				18	3347730	Receptacle (6-Way) (Use Term. 94613)
3	3347812	Clip, Harness	11	353424	Plug, Terminal (3-Way) (Power Cord) (Use Term.94613)	19	3349494	Connector, Etc
4	3352501	Clip, Harness				20	3407125	E.T.C. Control
5	90016	Clip, Harness	12	62505	Block, Disconnect (Motor 2 Speed) (Use Term.352088)	21	3948617	Connector (T.P.A.) (3-Circuit) (Lid Switch)
6	3390496	Clip, Harness	13	3347243	Block, Disconnect (Use Term. 352088)	22	3360056	Connector (T.P.A.) (3-Circuit) (Pressure Switch)
7	389379	Retainer, (Suds Models)	14	63523	Protector	23	3354925	Block, Connector (Cold Valve)
8	3948614	Timer, Block Disconnect (White)	15	717252	Connector (2-Way) (Use Term.94614)	24	3354926	Block, Connector (Hot Valve)
9	352089	Timer, Block Disconnect (Black)	16	3352944	Clip, Harness			


**FOR COMPLETE WIRING HARNESS REFER TO
CONTROL AND REAR PANEL PARTS PAGE**

WH2H

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

BRAKE AND DRIVE TUBE PARTS

For Models: LSR8010PQ0, LSR8010PT0
(Designer White) (Biscuit)



Illus. No.	Part No.	DESCRIPTION
1	388952	Brake And Drive Tube (Complete)
2	62658	Ring, Thrust
3	91939	Seal, Oil
4	356427	Seal, Drive Tube
5	356937	Spacer, Drive Tube
6	64027	Tube, Basket Drive (Includes Illus. 3, 4, 5 & 9)
7	64035	Ring, Retaining
8	64232	Shoe, Brake
9	62703	"T" Bearing, Spin Tube
10	62648	Cap, Brake Spring (2)
11	387806	Spring, Brake
12	62909	Sleeve, Brake Spring
13	63023	Cam, Brake Release
14	63022	Sleeve, Cam
15	64194	Driver, Brake Cam
16	90368	Ring, Retaining

FOLLOWING PARTS NOT ILLUSTRATED


285208 Lubricant
(Use Only In Brake Shoe Assembly On Roller & Pin)

BD-315-A

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

GEARCASE PARTS

For Models: LSR8010PQ0, LSR8010PT0
(Designer White) (Biscuit)




Illus. No.	Part No.	DESCRIPTION
1	3360630	Gearcase (Complete)
2	285202	Cover, Gearcase
3	3349985	Seal, Gearcase Cover
4	285195	Sealer, Gasket (.20 Fl. Oz.) (6 ml)
5	63320	Pinion, Spin (Includes Illus. 25)
6	356427	Seal, Spin Pinion
7	389387	Shaft, Agitator (Complete)
8	90369	Ring, Retaining (2)
9	62677	Retainer, Spring
10	62676	Spring, Agitate
11	63273	Gear, Agitate (Includes 15 and 29)
12	62619	Washer, Agitate Gear
13	62580	Cam Follower (Includes 14)
14	62581	Cam, Agitate (Includes 13)
15	285509	Shaft, Agitator (Includes 11 and 29)
16	62618	Washer, Cam Thrust
17	16018	Bearing, Thrust
18	85529	Ball, Bearing
19	389230	Bottom and Pinion, Gearcase
21	285352	Seal, Thrust Plug
22	3351614	Screw, Gearcase Cover, Mounting (8) (10-24 x 3/8)
23	3362552	Ring, Retaining
24	285735	Washer Kit, Thrust
25	62570	Gear, Spin
26	388253	Neutral Assembly
27	3349296	Rack, Connecting
28	62621	Actuator, Shift
29	388815	Washer, Intermediate

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

WATER SYSTEM PARTS

For Models: LSR8010PQ0, LSR8010PT0
(Designer White) (Biscuit)




WS400

Illus. No.	Part No.	DESCRIPTION
1	285442	Connector Kit, Plastic Drain Hose
2	285321	Sleeve Kit, (Contains 2 Sleeves)
3	370447	Clamp, Hose
4	16272	Connector, Straight
5	285320	Siphon Break Kit (Not Included)
6	65349	Clamp, Hose
7	367031	Drain Protector (Not Included)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

MISCELLANEOUS PARTS

For Models: LSR8010PQ0, LSR8010PT0
(Designer White) (Biscuit)



Illus. No.	Part No.	DESCRIPTION
1	3976263	Miscellaneous Parts Bag
2	3976300	Washer, Inlet Hose (4) (1-1/16 x 5/8)
3	3366912	Clamp, Hose
4	3359452	Nut, Lock (2) (3/8-16)
5	389102	Foot, Front (2)
6	3366913	Clamp, Hose

OPTIONAL PARTS (NOT INCLUDED)

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

PAINT, TOUCH-UP (1/2oz.)

72017 White
4392899 Biscuit

PAINT, PRESSURIZED SPRAY (12 oz.)

350938 Primer, Gray
350930 White
4392901 Biscuit

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

PAINT, BULK (1 qt.)

799344 White (Uncut)
4392900 Biscuit (Uncut)

OIL

350572 Oil, Gearcase (16 Oz.)

LUBRICANT

285208 Lubricant (Use Only in Brake Shoe Assembly On Roller and Pin)

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

SEALER

285195 Sealer, Gasket (.20 Fl. Oz.) (6 ml)

ACCESSORY PARTS

367031 Drain Protector
285320 Siphon Break Kit

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST